

Uitvoering	B cm	D cm	H cm	Stofgroep B	Stofgroep C	Stofgroep D	Stofgroep E	Stofgroep I
80 zonder armen	82	91	83	554	566	578	589	647
90 zonder armen	92	91	83	589	601	612	624	681
80 arm links	108	91	83	654	668	681	695	765
80 arm rechts	108	91	83	654	668	681	695	765
90 arm links	118	91	83	688	702	716	730	799
90 arm rechts	118	91	83	688	702	716	730	799
sofa arm links	108	168	83	1.007	1.023	1.040	1.056	1.120
sofa arm rechts	108	168	83	1.007	1.023	1.040	1.056	1.120
ottomane links	135	93	83	901	912	924	936	982
ottomane rechts	135	93	83	901	912	924	936	982
zithoek 112	112	112	83	834	850	866	882	963
zithoek 87	87	87	83	732	748	765	781	845
hocker	82	91	83	444	453	462	471	508
sofa XL arm links	118	168	83	1.065	1.081	1.097	1.113	1.178
sofa XL arm rechts	118	168	83	1.065	1.081	1.097	1.113	1.178
ottomane XL links	145	93	83	959	970	982	993	1.040
ottomane XL rechts	145	93	83	959	970	982	993	1.040

B = breedte, D = diepte, H = hoogte, in cm. Uitvoeringscodes volgens fabrikant: L/R = arm links of rechts, ZA = zonder arm, LCH = longchair, H = hoekelement.