

Uitvoering	B cm	D cm	H cm	Stofgroep B	Stofgroep C	Stofgroep D	Stofgroep E	Stofgroep I
75 zonder armen	75	106	82	663	683	705	727	802
90 zonder armen	90	106	82	685	708	730	752	841
150 zonder armen	150	106	82	1.014	1.054	1.091	1.131	1.242
75 arm links	102	106	82	767	792	824	854	953
75 arm rechts	102	106	82	767	792	824	854	953
90 arm links	117	106	82	792	817	841	866	965
90 arm rechts	117	106	82	792	817	841	866	965
150 arm links	177	106	82	1.121	1.168	1.210	1.257	1.396
150 arm rechts	177	106	82	1.121	1.168	1.210	1.257	1.396
loveseat	143	106	82	913	945	977	1.010	1.138
180 zonder armen	180	106	82	1.071	1.111	1.151	1.190	1.348
180 arm links	207	106	82	1.153	1.207	1.262	1.316	1.534
180 arm rechts	207	106	82	1.153	1.207	1.262	1.316	1.534
3 zits	204	106	82	1.252	1.306	1.358	1.410	1.576
4 zits	233	106	82	1.324	1.373	1.423	1.472	1.645
zithoek vast	106	106	82	802	834	866	898	1.027
zithoek verstelbaar	123	123	82	1.299	1.348	1.398	1.447	1.645
ottomane links	148	106	82	1.022	1.061	1.101	1.141	1.299
ottomane rechts	148	106	82	1.022	1.061	1.101	1.141	1.299
sofa arm links	118	174	82	1.121	1.160	1.200	1.240	1.398
sofa arm rechts	118	174	82	1.121	1.160	1.200	1.240	1.398
sofa arm links vast	118	174	82	1.057	1.096	1.136	1.175	1.334
sofa arm rechts vast	118	174	82	1.057	1.096	1.136	1.175	1.334
hocker	90	106	82	448	465	482	500	569
cats & dogs	90	106	82	639	651	663	675	722

B = breedte, D = diepte, H = hoogte, in cm. Uitvoeringscodes volgens fabrikant: L/R = arm links of rechts, ZA = zonder arm, LCH = longchair, H = hoeelement.