

Uitvoering	B cm	D cm	H cm	S1	S2	EKO	EKO (2)	B / C	D	E	F
4	298	96	77	1.965	2.062	2.262	2.319	2.986	3.316	3.483	3.707
3,5	273	96	77	1.815	1.906	2.095	2.141	2.755	3.065	3.219	3.428
3	248	96	77	1.661	1.743	1.919	1.963	2.524	2.805	2.946	3.138
2,5	223	96	77	1.514	1.589	1.743	1.787	2.297	2.555	2.684	2.854
2	198	96	77	1.362	1.428	1.569	1.609	2.068	2.299	2.416	2.570
1,5	148	96	77	1.213	1.272	1.400	1.430	1.840	2.046	2.150	2.288
1	118	96	77	1.061	1.114	1.226	1.254	1.611	1.791	1.881	2.002
HOCKER	100	50		335	355	370	379	445	487	513	564

B = breedte, D = diepte, H = hoogte, in cm. Uitvoeringscodes volgens fabrikant: L/R = arm links of rechts, ZA = zonder arm, LCH = longchair, H = hoekelement.

Stoffen en leder per groep

- S1: BELLA, MISCANTO, SEMPRE, TORO, TRENZA
- S2: ADORE, BE GENTLE, BE LOVELY, BERGEN, BRAVE, CAYENNE, COCO, ENTER, FUSION, JEEP, LEAF, LODGE, MACAN, MIAMI, MITO, RIVER, SHEEP, SILENT, VENG
- EKO: BULL, HOME, JERSEY
- EKO (2): BONANZA
- B / C: TOLEDO
- D: ALHAMBRA, GRANADA, KENIA, TOUCH, VINTAGE
- E: PRESTIGE
- F: MATADOR, TRIBE

