

Uitvoering	B cm	D cm	H cm	S1	S2	EKO	EKO (2)	B / C	D	E	F
1	90	70	82	517	542	566	581	685	724	762	852
HOCKER	65	47	43	212	220	225	231	271	297	313	330

B = breedte, D = diepte, H = hoogte, in cm. Uitvoeringscodes volgens fabrikant: L/R = arm links of rechts, ZA = zonder arm, LCH = longchair, H = hoekelement.

Stoffen en leder per groep

S1: BELLA, MISCANTO, SEMPRES, TORO, TRENZA

S2: ADORE, BE GENTLE, BE LOVELY, BERGEN, BRAVE, CAYENNE, COCO, ENTER, FUSION, JEEP, LEAF, LODGE, MACAN, MIAMI, MITO, RIVER, SHEEP, SILENT, VENG

EKO: BULL, HOME, JERSEY

EKO (2): BONANZA

B / C: TOLEDO

D: ALHAMBRA, GRANADA, KENIA, TOUCH, VINTAGE

E: PRESTIGE

F: MATADOR, TRIBE

